

Accessories for projector mounts

Illustration	Model	Specification	Ref. No.
	Carrying tray	<ul style="list-style-type: none"> For projectors, players etc. Surface: 32 x 32 cm Max. height: 16 cm Suitable for Premium Line mounts Can be mounted directly on the ceiling 	5879 000 000
	Holding bracket	Set of 2 clamps for fixing the ceiling mount on tube-shaped supports (truss) with max. 30 - 70 mm diameter.	5873 000 000
	Tiltable joint	For fixing mounts of the Comfort ² Line, Premium Line on sloping ceilings. Max. inclination 45°	7450 000 013

Accessories for Premium Line

Illustration	Model	Specification	Ref. No.
	Set of longer spider arms for large projectors	For fixing on mounts of the Premium Line (7450000xxx), e. g. for Panasonic EX/EW/EZ/DZ series, Sony FH series (as of FH60) Max. distance of the drill-holes on the projector: 493 mm	5883 000 001

Accessories for Premium wall mounts

Illustration	Model	Specification	Ref. No.
	Cover plate for wall mounting	For Premium W50 / W70 / W140 white, RAL 9003	7452 000 010

Anti-theft protection

Safety against theft and vandalism



Anti-theft device

- For notebooks, projectors etc.
- Plastic coated steel rope

Anti-theft device with security lock slot, length 1.5 m, diameter 4 mm	5775 000 000
Anti-theft device as 5775 000 000 but simultaneous locking	5775 000 001



Two-element anti-theft device

The two-element anti-theft device effectively protects projectors which are fixed to a ceiling mount against unauthorized removal.

The system is compatible with all Kindermann ceiling mounts and can be added later.

- A high-quality "ABUS" safety rope with lock (rope 11 mm diameter) makes it impossible to disconnect the projector from the holder
- A special safety rope additionally secures the projector holder on the ceiling



Two-element anti-theft device , rope length 95 cm	7426 000 000
Two-element anti-theft device , rope length 200 cm	7426 000 200